



Installation Notes:

- 1.) Skirt moves with the mold
- 2.) Skirt is mounted with supplied magnets and Velcro
- 3.) Skirt can be hung onto platens
- 4.) Skirt can be hung from machine chassis

Please email completed form to sales@partcontainment.com

PLEASE FILL IN A, B, C, D, E & F:

- A = Distance across widest point of platens or machine chassis
B = Length of skirt required
C = Widest point of "Tool Open" of full platen open

All dimensions are measured in inches, unless otherwise specified

Contact Information

Company Name:

Contact Name:

Email:

Phone: